

MB MASTER-BILT[®]

Refrigeration Solutions



Master Controller 2.0v24 Reverse Cycle Defrost System

Installation & Operations Manual

**An Electronic Microprocessor-Based
Electric/Mechanical Expansion Valve Refrigeration Control System
With TCP/IP Internet Monitoring Feature**

May 2015
PN 888-88889

*©2015 Master-Bilt Products, an unincorporated division of Standex International Corporation. All rights reserved.
Printed in U.S.A.*



IMPORTANT NOTICES

- **Read this manual before installing your Master Controller 2.0 system. Keep the manual and refer to it before doing any service on the equipment. Failure to do so may result in personal injury or waive warranty of damaged equipment.**
- Modifications to existing equipment are subject to approval by Master-Bilt and must be explicitly written. There are no implied flexibilities designed into this product.
- The following points apply unless overwritten and approved by the Master-Bilt engineering department:
 - Maximum distance of wires between the evaporator and the Master Controller 2.0 MUST not exceed 40 ft.
 - The Master Controller 2.0 MUST be mounted on the neighborhood of the vestibule entrance door for below -40°F extra low temp freezer
 - All sensor wires MUST be in separate metal conduit from power wiring and control wiring for below -40°F extra low temp freezer
- Due to continuous product enhancements, Master-Bilt reserves the right to make engineering changes and change specifications for product improvement without notice.

TABLE OF CONTENTS

INTRODUCTION	4
WARNING LABELS AND SAFETY INSTRUCTIONS	5
APPLICATIONS.....	5
MASTER CONTROLLER LAYOUT	6
Description	7
Factory-Mounted Parts.....	8
Features	9
Sequences of Operation	10
START UP	10
OFF MODE	10
COOL MODE	10
DEFROST MODE	11
Scheduled Defrost	11
Demand Defrost	12
Manual Defrost	12
COIL DRAIN MODE	12
FAN DELAY MODE.....	12
SAFETY MODE	12
Multiple Evaporator Configuration	13
BOND CONTROLLERS FROM FRONT PANEL	14
SYCHRONIZE MODE (peer to peer)	14
ALTERNATING MODE	14
Definition of On-Board Symbols.....	15
STATUS, DEFAULT AND READING DISPLAY	15
VARIABLES	15
MANUAL MODE.....	15
TYPICAL SETPOINTS PARAMETER	16
ALARM DISPLAY	17
Setting Parameters by On-Board Pushbuttons	17
Temperature Sensors	19
SENSOR SERVICE INSTRUCTIONS.....	19
Pressure Transducer	20
Charging the Master Controller 2.0 Refrigeration System.....	21
Technical Notes	22
REVERSE CYCLE DEFROST	23
General Information	23
Advantages	23
Factory-Installed Parts	23
Eliminated Parts	24
Defrost Time	24
Charging a Master Controller 2.0 System Equipped with Reverse Cycle Defrost ...	24
ELECTRIC WIRING.....	24
TYPICAL WIRING DIAGRAMS	25-27
TROUBLESHOOTING GUIDE	28
Troubleshooting Electric Expansion Valve	29
MASTER-BILT PART NUMBERS.....	29

INTRODUCTION

Thank you for purchasing a Master-Bilt Master Controller 2.0 for Electric or Reverse Cycle Defrost system. This manual contains important instructions for installing, using and servicing the system as well as a parts list. Read this manual carefully before installing or servicing your equipment.



DANGER

Improper or faulty hook-up of electrical components of the refrigeration units can result in severe injury or death.

All electrical wiring hook-ups must be done in accordance with all applicable local, regional or national standards.



NOTICE

Installation and service of the refrigeration and electrical components must be performed by a refrigeration mechanic and/or a licensed electrician.

The portions of this manual covering refrigeration and electrical components contain technical instructions intended only for persons qualified to perform refrigeration and electrical work.

This manual cannot cover every installation, use or service situation. If you need additional information, call or write us:

Customer Service Department
Master-Bilt Products
Highway 15 North
New Albany, MS 38652
Phone: 800-684-8988
Fax: 866-882-7629
Email: service@master-bilt.com

WARNING LABELS AND SAFETY INSTRUCTIONS



This is the safety-alert symbol. When you see this symbol, be alert to the potential for personal injury or damage to your equipment. Be sure you understand all safety messages and always follow recommended precautions and safe operating practices.



NOTICE TO EMPLOYERS

You must make sure that everyone who installs, uses or services your refrigeration is thoroughly familiar with all safety information and procedures.

Important safety information is presented in this section and throughout the manual. The following signal words are used in the warnings and safety messages:


DANGER: Severe injury or death will occur if you ignore the message.

WARNING: Severe injury or death can occur if you ignore the message.

CAUTION: Minor injury or damage to your refrigeration system can occur if you ignore the message.

NOTICE: This is important installation, operation or service information. If you ignore the message, you may damage your refrigeration system.

The warning and safety labels shown throughout this manual are placed on your Master-Bilt refrigeration system at the factory. Follow all warning label instructions. If any warning or safety labels become lost or damaged, call our customer service department at 800-684-8988 for replacements.



This label is on the housing of the Master Controller 2.0 typically located on an evaporator coil.

APPLICATIONS

Master Controller 2.0 Electric/Reverse-Cycle Defrost systems are designed to control Master-Bilt made condensing units and evaporators for freezer and cooler applications. Each system contains a condensing unit, evaporator(s) with Master Controller 2.0 board(s), Mechanical/electric expansion valve(s), pressure transducers, temperature sensors, reverse cycle valve and operational controls.

MASTER CONTROLLER

Description

The Master Controller 2.0 is a custom-designed microprocessor-based electronic controller for Master-Bilt refrigeration products. The controller capable to control an electric expansion valve in response to evaporator superheat and return air temperature. The hardware and input/output descriptions and connections of a Master Controller 2.0 are shown below.




Figure 1 . Master Controller 2.0 Board Layout.

- **SEI or SER Terminals.** Sporlan SEI and SER type electric expansion valves are currently used for all applications. There are 1596 nominal steps for entire valve stroke.
- **Pressure Transducer** is mounted at the evaporator suction header to measure saturated suction pressure in absolute value but displayed in gauge pressure in PSIG. The suction pressure is converted to evaporating temperature. The difference between outlet temperature and evaporating temperature is the true superheat displayed as “**SUPH**”.
- **Defrost Termination Temperature Sensor TS3** is mounted downstream of the distributor tube after the valve and close enough to the evaporator coil to measure defrost termination temperature during defrost cycle. Figure 2 on the previous page shows the sensor locations of the evaporator and the controller.
- **Outlet/Fan Cut-In Temperature Sensor TS1** is mounted on the suction line about 6” to 10” away from the evaporator to measure outlet temperature during cooling cycle and to serve as evaporator fan cut-in temperature sensor. The sensor is at a 2 or 10 o'clock position on the suction line. The default value of the fan cut-in temperature is pre-set at 20°F for commercial refrigeration application.
- **Room Temperature Sensor TS2** is typically mounted with a plastic tie at the drain pan on the side of the evaporator return air. It is located around the middle of the evaporator to allow even air flow across it. If necessary, it can be relocated to a spot with better representation of the cold room temperature.
- **Four Digit LED Display** is used to show status of the controller, set point values and temperatures.
- **Green Amber and Red LED Status Indicators.** The green LED will be on when the compressor relay is energized. The green LED will blink when the air temperature is satisfied, but the compressor minimum run timer or minimum off timer has not yet timed out. The red LED indicates a critical alarm has occurred (Low Pressure alarm). The amber LED indicates all other alarms.
- **Six Push Buttons** are used to display set points and status as well as to reset operational parameters like room temperature, defrost mode, number of defrosts, etc. Their functions can be also performed by using the TCP/IP interface.
- **Two 20 Amp, 240 VAC NC/NO Relays.** One relay is used for the defrost heater when the heater load is less than 20 amp. It will be wired to defrost heater contactor when heater load is over 20 amp or three phase heaters. **For a reverse cycle defrost system, it is wired to a 40VA transformer that provides 24VAC power to the reversing valve solenoid coil.** The other relay is used to switch evaporator fans ON and OFF. A fan contactor will be used if the fan motor is larger than 10 amps or three phase or the voltage is different from control voltage.
- **One 3 Amp, 240 VAC NC/NO Relay** is used for the compressor contactor or liquid line solenoid.
- **One 3 Amp, 240 VAC NC/NO Relay** is an option for an external alarm system. The customer can decide what type of a physical alarm is used. This relay is energized when the controller is powered on. Whenever the controller gives an alarm, the relay will be de-energized. For example, a technician can connect a phone alarm system to this relay. When there is an alarm, the alarm system can dial in his pager or cellular phone.
- **One RJ-45, TCP/IP Ethernet Port** is used for Peer to Peer system or an alternating system communication requiring ethernet connection. It is also used to communicate with a Laptop, internal network, or the internet.
- **Power Input 120 or 208/240 VAC.** For 120 VAC input, jumper between pins 1 and 2 of ‘Voltage Jumper’ connector and jumper between pins 3 and 4 of ‘Voltage Jumper’ connector. For 208/240 VAC input, jumper between pins 2 and 3 of ‘Voltage Jumper’ connector.




Figure 2.

Factory-Mounted Parts

- A controller board, an Electric/Mechanical expansion valve, a pressure transducer, and three temperature sensors for single evaporator system (standalone or alternating) or peer (multiple evaporator system) evaporator are pre-mounted at the factory. . For a multiple evaporator system, only 1 evaporator is required to have an air temperature sensor. For reverse cycle defrost, a 24 VAC 40VA transformer is mounted at standalone or master evaporator to provide power 24VAC to the four-way reversing valve mounted in the condensing unit. The control circuit and power supply are pre-wired to the terminal board of the evaporator. The board is molded in epoxy to avoid excessive moisture in cold room.
- A 4-way reversing valve, operating at 24 VAC, is installed in a reverse cycle defrost equipped unit. A transformer is also installed in one of the evaporators to supply 24VAC to the 4-way reversing valve.
- Peer to Peer controls can be connected directly to each other, using a CAT-5E cable, if there are only 2 controllers. The controllers must be connected through an Ethernet switch or router if 3 or more controllers are on the system. The controllers must be bonded together. A technician should install the CAT-5E cable from the controllers to the Ethernet switch or router and bond the controllers. All components are factory tested. A technician should check all the wiring and settings for proper operation after installation.

Features

- One of the most energy-saving features of the Master Controller 2.0 Reverse Cycle Defrost system is free floating head pressure. A head pressure control is not installed on Master Controller 2.0 systems. Without this control, compressors work at the highest efficiency at the lowest possible condensing pressure rather than at the limited pressure level typically found in conventional systems using a head pressure control valve for low ambient environments. For more energy saving information, go to www.master-bilt.com/pdfs/master_controller_vs_standard_system.pdf.
- Option for Mechanical Expansion Valve, or Electronic Expansion Valve
- With the electric expansion valve; the refrigerant flow of the electric expansion valve is modulated by the true superheat, or the difference of evaporator outlet and evaporating temperatures.
- The room temperature sensor replaces the conventional temperature control. The temperature is set with the pushbuttons on the Master Controller 2.0 board or through the web page. The default temperature must be checked during the first startup of the machine against actual application temperature. Default must be re-set to actual application temperature if there is a discrepancy.
- Evaporator Fans cycle during compressor off mode, and options for electric defrost heaters to cycle on-and-off during defrost for additional energy saving.
- The on-board timer is used for run time control and scheduling defrosts. No mechanical defrost timer is necessary for this system. Once the power is turned on, the timer starts counting.
- The Master Controller 2.0 has the capability to perform scheduled defrost or demand defrost for either Reverse Cycle hot gas defrost, or Electric defrost.
 - When the scheduled defrost scheme is chosen, the on-board timer is used for scheduled defrosts. The system works in the same fashion as a regular conventional system with mechanical defrost timer.
 - When the demand defrost is chosen, the controller will not initiate a defrost unless it is needed. The low temperature system is pre-set with demand defrost.
- The demand defrost scheme is a pioneer design by Master-Bilt for freezer applications. Extensive lab tests indicate that many unnecessary defrosts are eliminated and energy consumption reduced when using demand defrost compared to using a conventional refrigeration system equipped with a mechanical defrost timer.
- The operational status of modes, room temperature and alarms is displayed on the four-digit on-board display.
- Manual defrost is available on standalone and Peer to Peer systems.
- All components are factory-mounted, pre-wired and tested to save on-site installation labor and reduce chance of installation errors.
- The superheat set point has a wide adjustability range 5° to 20 °F. This range allows the controller to meet different customers' needs, and require less refrigerant charge for winter operation than conventional refrigeration unit when no head pressure valve is installed in the condensing unit.
- The controller can be used in low, medium and high temperature applications. The internal programming will recognize the input of room temperature set point (**RMSP**) and automatically select appropriate segments of the program for the application.
- The patented reverse cycle defrost control (**United States Patent 7,073,344**) reduces defrost energy usage by up to 80% and decreases defrost time from 20-45 minutes (freezer equipped with electric heaters) to 3-5 minutes in a freezer or 1½ – 2 minutes in a cooler with a completely clean defrost.
- Maximum operating suction pressure can be controlled by the electric expansion valve eliminating the crankcase pressure regulator for some applications.
- Minimum operating suction pressure provides additional compressor protection.

Sequences of Operation

START UP

When power is applied to the board, the controller closes the valve. The controller will display 'STUP' on its four-digit display for five seconds. It will then display 'CKFN' on the four-digit display for 10 seconds. The evaporator fans will be on for the first 15 seconds allowing a service technician time to check them. The controller will then turn the fans off and check each sensor. The controller will check the pressure transducer for a short or open. It will display 'CKPR' on the four-digit display for three seconds. If the sensor fails, the controller will display an alarm and go to safety mode for a failed sensor. If the sensor passes, it will display 'OKPR' on the four-digit display for three seconds. The controller will check the sensor connected to 'TS1' for a short or an open. It will display 'CKT1' on the four-digit display for three seconds. If the sensor fails, the controller will display the alarm 'STSA' on the four-digit display and go to safety mode for a failed suction sensor. If the sensor passes, it will display 'OKT1' on the four-digit display for three seconds. The controller will check the sensor connected to 'TS2' for a short or an open. It will display 'CKT2' on the four-digit display for three seconds. If the sensor fails, the controller will display the alarm 'ATSA' on the four-digit display and go to safety mode for a failed air sensor. If the sensor passes, it will display 'OKT2' on the four-digit display for three seconds. The controller will check the sensor connected to 'TS3' for a short or an open. It will display 'CKT3' on the four-digit display for three seconds. If the sensor fails, it will display the alarm 'CTSA' on the four-digit display and go to safety mode for a failed coil temperature sensor. If the sensor passes, it will display 'OKT3' on the four-digit display for three seconds. If all sensors pass, the controller will display 'CKFH' on the four-digit display for six seconds.

The controller will not go into defrost during the preceding start up procedure. It will check the number of defrosts per day (DFPD) and time_of_day (HOUR, MIN). If it is time for the controller to be in defrost, it will start in DEFROST mode. If not, the controller will start in COOL(REFR) mode after fan delay.

The set points are stored in EEPROM (Electrically Erasable Programmable Read Only Memory). Batteries are not required to store the new set points. If power is lost, the set points which were in the controller at that time will be used when power is restored.

OFF MODE (OFF)

The controller starts in OFF mode by fully closing the valve. The controller will keep the valve closed for the minimum OFF Time (MOTM) in order to keep the compressor in pumpdown or off for a minimum amount of time. When the room temperature reaches the cut-in set point (room temperature set point "RMSP" plus the temperature difference set point "ADIF"), the controller goes to COOL mode (REFR).

If a scheduled defrost scheme is selected, while the controller is in OFF mode, it is constantly checking the number of defrosts per day and the time_of_day and calculating the time for defrost. When the time_of_day is right for a defrost, it will immediately go into DEFROST mode right after the current OFF mode.

If the demand defrost scheme is selected, defrost will be checked and initiated only during the COOL mode.

After the Minimum OFF Time is timed out and the room temperature reaches the Cut-In temperature, the controller will go into COOL mode (REFR).

While in OFF MODE, the four-digit display on Master will show 'OFF' for three seconds, 'RMTP' for two seconds, and the numerical display of the room temperature for five seconds. The four-digit display on controllers without an air temperature sensor will show 'OFF'.

COOL MODE (REFR)

The controller starts COOL mode by opening the valve. The condensing unit will start by a suction line low pressure control cut-in. The electric expansion valve is modulated by the controller so that a preprogrammed superheat set point is maintained during the refrigeration process. Actual superheat is the temperature difference of the evaporator outlet and the evaporating temperature converted from the reading of the pressure transducer, or $T_{out} - T_{sat}$. The controller will keep modulating the valve so the superheat will equal the superheat set point. Meanwhile, the controller reads also the room air temperature TS2. When the room temperature is below the room temperature set point (pre-set to -10 °F for low temp), it goes back to OFF mode. All the time that the controller is in COOL mode, it is constantly checking the criteria to determine if a defrost should be initiated. It will immediately go into DEFROST mode (DEFR) when defrost criteria are met.

If the suction pressure is above the maximum operating pressure set point (MOP), the valve will modulate to control the pressure at or below the maximum operating pressure set point (MOP). When the operating suction pressure is lower than MOP, it will go back to superheat control. Suction pressure is used to calculate saturated temperature (TSAT).

If the suction pressure is below the Minimum pressure set point (MNPR), the valve will close and the control signal to the external relay will be turned off. It will resume normal operation when the pressure is above the Minimum pressure set point.

While in COOL MODE, the four-digit display on Master will show 'REFR' for three seconds, 'RMSP' for two seconds, and the numerical display of the room temperature for five seconds. The four-digit display on controllers without an air temperature sensor will show 'REFR'.

DEFROST MODE (DEFR)

There are two methods to determine if a defrost will be initiated for the Master Controller: scheduled defrost and demand defrost. If the parameter "DINM" = "DEMD" and the number of defrosts per day 'DFPD' is set to 0, the controller will do the demand defrost by default. If the parameter "DINM" = "SCHD" and the number of defrosts per day 'DFPD' is set from 1 to 8, the controller will do the scheduled defrost.

IMPORTANT NOTE:

In the controller, the parameter of "DFMD" has to be set for proper method of defrost. "DFMD = ELEC" is for regular electric defrost; "DFMD = RCD" is for regular reverse cycle defrost;

Scheduled Defrost

The following is the description of the scheduled defrost.

The time_of_day is really an elapsed counter that counts the number of minutes that have passed. An elapsed count of 0 is 12:00 AM. The count goes up to 1439 which corresponds to 11:59 PM. The counter then will reset to 0.

The time of day will be kept as long as input power is connected. If input power is turned off, then back on, the time of day will be reset to 0 which corresponds to 12:00 AM.

The first defrost start time is an elapsed time of 0 (12:00 AM). The subsequent defrost start times are determined by adding the number of minutes between each defrost to the previous start time until there is a defrost start time for each defrost per day. The number of minutes between each defrost is determined by taking 1440 / number of defrosts per day as set up by the 'DFPD' set point.

When starting an electric defrost, FAN relay is de-energized to turn off the fans. The controller waits for five seconds, then the DEFROST relay is energized to start a defrost.

When starting a reverse cycle defrost, the FAN relay is de-energized to turn off the fans while, at the same time, COMPRESSOR relay is de-energized to turn off the compressor. There is a 10 second delay before the DEFROST relay is energized to switch the four-way reverse valve. Then there is a 30 second waiting period for pressure equalizing. Afterward, COMPRESSOR relay is energized to turn the compressor. Hot gas will be reversed to flow to the evaporator while the electric expansion valve is modulated to start a defrost.

The controllers use the coil sensor 'TS3' as the defrost termination sensor. When this temperature gets above the preprogrammed Defrost Termination Set Point (DTSP) before the preprogrammed Maximum Defrost Time (MXDT), the defrost will terminate. Otherwise, it will be terminated when the Maximum Defrost Time (MXDT) times out.

While in DEFROST MODE, the four-digit display will be 'DEFR' for three seconds, 'DTTP' for three seconds, and the numerical display of the temperature reading from sensor TS3 for three seconds.

Demand Defrost

When “DINM” = “DEMD” and ‘DFPD’ is set to ‘0’, the controller will initiate a demand defrost. The controller will not go to ‘DEFROST MODE’ until a heavy frost accumulation is in the evaporator coil. When frost is built up in the evaporator, it will block the air flowing through the evaporator coil and reduce the heat transfer area. It will also decrease the evaporating temperature, which, in turn, increases probability of frosting. A demand defrost scheme to detect the frost build-up and the criteria to start defrost are programmed in the Master Controller. Unlike scheduled defrost, the Master Controller 2.0 with demand defrost is really an energy saver. If no selection is made, the controller will automatically select demand defrost when the power is applied to the controller. The defrost procedure is the same as described for the scheduled defrost.

After selecting the demand defrost, if the elapsed time since the last defrost has been a selectable time (INTV) from 8 hours (480) to 72 hours(4320), the Master Controller 2.0 will go into defrost to ensure a proper oil return.

Manual Defrost

The controller allows manually-initiated defrost when needed. The manual defrost will be disabled if the evaporator inlet sensor detects the temperature higher than the defrost termination temperature. Operation of the manual defrost will be discussed in a later section.

COIL DRAIN MODE (DRAN)

The controller automatically goes into COIL DRAIN whenever a defrost is terminated. The controller stays in this mode for the preprogrammed ‘DRIP TIME’. When this time is completed the controller opens the expansion valve and goes into FAN DELAY mode (FNDL).

While in COIL DRAIN MODE, the four-digit display on the controller will show ‘DRAN’ for five seconds, ‘RMTP’ for three seconds, and the numerical display of the room temperature for three seconds. The four-digit display on controllers without an air temperature sensor will show ‘DRAN’.

FAN DELAY MODE (FNDL)

The controller will pull down the temperature of the evaporator without the fans on until one of the following occurs: The FAN DELAY TIME setpoint times out, standard five minutes, or the fan cut-in sensor’s temperature (FDTP) TS1 goes below the FAN DELAY TEMPERATURE Setpoint . The controller will then go into COOL mode.

While in FAN DELAY MODE, the four-digit display will be ‘FNDL’ for three seconds, ‘FDTP’ for three seconds, and the numerical display of the temperature reading from sensor TS1 for three seconds.

SAFETY MODE

When an alarm occurs, such as a sensor failure or a communication alarm, the controller will go into ‘SAFETY MODE’. SAFETY MODE provides minimum refrigeration to the refrigerated room before the corrective action is taken and the alarm is cleared. The system will do the following in Safety Mode:

- Pressure transducer alarm (PRSA)
 - Cool mode
 - Valve open for the minimum compressor run time
 - Valve closed for the minimum compressor off time
 - Keep doing above cycle until alarm goes away
 - Ignores maximum pressure control mode
- Outlet sensor alarm (STSA)
 - Cool mode
 - Valve open for the minimum compressor run time
 - Close valve for the minimum compressor off time
 - Keep doing above cycle until alarm goes away.
 - Fan delay mode
 - Lets fan delay time out (five minutes)

- Defrost Mode
 - If this alarm and defrost term temp sensor alarm, reverse cycle defrost will last only three minutes with valve open;
 - If this alarm and defrost term temp sensor alarm, electric defrost will last only ten minutes with valve closed.
- Room temp sensor alarm (ATSA)
 - Cool Mode
 - Run on superheat control for the minimum compressor run time
 - Close valve for the minimum compressor off time
 - Keep doing above cycle until alarm goes away.
- Low superheat alarm (LOSH)
 - Close valve and wait for alarm to go away.
- High Room Temperature Alarm (HITA)

The 'high room temperature alarm' occurs when the room temperature is above the preprogrammed 'HIGH TEMPERATURE ALARM' for a preprogrammed number of minutes. The alarm is cleared when the room temperature is less than the 'HIGH TEMPERATURE ALARM' set point.
- Low Room Temperature Alarm (LOTA)

The 'low room temperature alarm' occurs when the room temperature is below the preprogrammed 'LOW TEMPERATURE ALARM' for a preprogrammed number of minutes. The alarm is cleared when the room temperature is above the 'LOW TEMPERATURE ALARM' set point.
- Defrost term temp sensor alarm (CTSA)
 - Defrost mode
 - Open valve until alarm goes away or defrost terminates.
 - If this alarm and outlet temp sensor alarm, defrost will last only three minutes.
 - Use outlet sensor for defrost temperature termination
- Communication alarm (COMA)
 - For Alternating mode, (ALTN) go to standalone mode.
 - For Synchronous mode, (SYNC)
 - Cool mode
 - Run on superheat control for the minimum compressor run time
 - Close valve for the minimum compressor off time
 - Keep doing above cycle until alarm goes away.
 - Pumpdown Mode
 - Wait until pump down time times out.
 - Drip Mode
 - Wait until Drip time times out.
 - Defrost Mode
 - Valve will close when defrost termination temperature meets its set point if reverse cycle defrost. Valve will close at all time if electric defrost. It will then wait the full defrost time for other evaporators to defrost..
 - If in demand defrost mode, defaults to three defrosts per day.

Multiple Evaporator Configuration

The Master Controller 2.0 can be configured with 1 to 8 other controllers. Each controller is appointed a static I/P address at the factory for communication and sequence of operation. The evaporators are piped together to one condensing unit. The room temperature sensor is mounted on any of the controllers. All controllers can have a room temperature sensor connected for better control. All evaporators have a pressure transducer, outlet sensor and coil sensor. All controllers will communicate with each other to share the room temperature reading and the coil temperature reading. All controllers can modulate its electric expansion valve independently.

- The communication cable is a CAT/5E cable, up to 330 feet.
- Communication for peer to peer control are connected to the RJ-45 connector.

BOND CONTROLLERS FROM FRONT PANEL

- Connect to Ethernet switch or router only the controllers that you want to bond.
- On any controller, using the left and right buttons, go to Manual Mode (MNMD).
- Press 'ENTER', display will show Password (PSWD), press 'ENTER'
- Using the left, right, up and down buttons enter '0002' and hold 'ENTER' button until display shows one of the manual modes.
- Using the up and down buttons, go to 'BOND', press 'ENTER', display will show 'ITBD' (initialize bond).
- Press and hold the 'ENTER' button until display shows 'MNMD'. After about 5 seconds, all controllers will reset. They are then bonded.

SYNCHRONIZE MODE (Peer to Peer)

When power is turned on, that controller will initialize itself by closing the valve. A 'ROOM TEMPERATURE' sensor is needed to be connected to only one Controller. A 'ROOM TEMPERATURE ALARM' is set only if none of the controllers have a good air temperature sensor connected. If it does not have a room temperature sensor connected, it will put itself in 'COOL' mode and wait to get the room temperature from another controller. If it does not receive any command within a minute, it will set the 'communication alarm' and then run in 'SAFETY MODE' as described previously. The 'communication alarm' clears when it receives any command from that controller.

The controllers switch between 'COOL' mode and 'OFF' mode based on the warmest temperature reading from all controllers that have a room temperature sensor.

If any controller decides to go in defrost, all controllers will then go into defrost.

If any controller decides to go in drain mode, all controllers will then go into drain mode.

If any controller decides to go in fan delay mode, all controllers will then go into fan delay mode

If there is a communication alarm at any controller, then the controller will go into defrost as a scheduled defrost that will terminate on time only.

ALTERNATING MODE (between 2 controllers)

The controller can be configured as an alternating system for dual single-evaporator refrigeration units to provide redundancy of a refrigerated cold room. Once the network is set up, a CAT/5E cable can be connected between the 2 controllers or a switch/router, connected to the RJ-45 connector.

When the alternating mode is selected, the dual refrigeration units will start pulling down box temperature to the cut-out set point then both go into OFF MODE(OFF). When the box temperature rises up to cut-in temperature, the one of the units will come on while the other stays off. The other evaporator will perform the refrigeration in next cooling cycle.

When the Lead Lag mode is selected, the first controller (lead) will run as stand alone control for the number of hours as is set "TBLL". The other controller will stay off (Lag mode) for that same amount of hours. After the one controller has been running and the other control has been off and in lag mode for the number of hours in 'Time Between Lead/Lag' (TBLL), the first controller will go in Lag mode and the second controller will first go through a defrost cycle, then run as a stand alone control. The above cycle will keep repeating. If one controller have an alarm beside the door alarm; then the other become the Lead then the one that have alarm will become the Lag. If both controller have the alarm beside door alarm; the the controller will stay in the current mode.

Definition of On-Board Symbols

STATUS, DEFAULT AND READING DISPLAY

When the on-board green light is on, the compressor relay is energized. When the green light is blinking, the room temperature sensor is satisfied, but waiting for the minimum off time or minimum run time to time out. When the red light is on, there is a critical alarm. When the amber light is on, there is a non-critical alarm.

The status and the digital data are displayed on the onboard four-digit LED display. Below is a list of the parameters of the operational status.

On-board Four-Digit

Display Description

STUP	Indicates the status of Start Up Mode
CKFN	Check fan working status
CKP1	Check pressure transducer
OKP1	Indicates the pressure transducer is working
CKT1	Check sensor TS1, the suction/fan cut-in sensor
OKT1	Indicates the TS1 is working as it should
CKT2	Check sensor TS2, the room temp sensor
OKT2	Indicates the TS2 is working
CKT3	Check sensor TS3, the coil temp sensor
OKT3	Indicates the TS3 is working

On-board Four-Digit

Display Description

CKFH	Indicates all sensors are OK
FNDL	Indicates FAN DELAY MODE
FDTP	Actual TS1 value in FAN DELAY
COOL	Indicates COOL MODE
OFF	Indicates OFF MODE
PMDN	Indicates PUMPDOWN MODE
DEFR	Indicates DEFROST MODE
DRAN	Indicates COIL DRAIN MODE
DFTP	Inlet Sensor TS3 value in DEFROST MODE
LAG	Standby controller of Lead/Lag C

A list of the parameters that can be displayed and/or changed is shown below when access to the default settings is needed. This access is usually done by a trained technician.

VARIABLES

“VARI”

Description	
RMTP	Room Temperature
SUPH	Superheat
PRES	Suction Pressure Reading
TSUC	Suction Temperature Reading
TSAT	Saturated Temperature
TCOI	Coil Temperature
VALV	Expansion Valve Position
STAT	Status REFR/OFF/DEFROST/DRAIN/FAN DELAY
ALCM	ON
RLDF	Defrost Relay ON/OFF
RLFN	Fan Relay ON/OFF
ALAU	AUX Relay ON/OFF

D1ST	DIGITAL Input 1 Status
D2ST	DIGITAL Input 2 Status
D3ST	DIGITAL Input 3 Status
IPQ1	1 ST Quadrant of IP Address
IPQ2	2 nd Quadrant of IP Address
IPQ3	3 rd Quadrant of IP Address
IPQ4	4 th Quadrant of IP Address
NET1	1 ST Quadrant of Subnet Mask
NET2	2 nd Quadrant of Subnet Mask
NET3	3 rd Quadrant of Subnet Mask
NET4	4 th Quadrant of Subnet Mask
FWRV	Firmware Version V3.98

MANUAL MODES

“MNMD”

MCTL	MANUAL STATUS
MVLV	MANUAL VALVE
CLAL	CLEAR ALARM
BOND	BOND CONTROLLERS

TYPICAL SET POINTS FOR AMC CONTROLLER 2.0

SETPOINT	masterbiltstandex@gmail.com	Air/Electric Defrost		Reverse Cycle Defrost	
"STPT"	DESCRIPTIONS	Freezer	Cooler	Freezer	Cooler
RMSPT	Room Air Setpoint	-10	35	-10	35
ADIF	Room Air Differential	5	5	5	5
MRTM	Minimum RUN Time	2	2	2	2
MOTM	Minimum OFF Time	2	2	2	2
MNPR	Minimum Suction Pressure Setpoint	0	15	0	15
T4TP	AUX Temp Functionality DISA/T4RT/4CL	DISA	DISA	DISA	DISA
REL4	AUX Relay Functionality ALMR/2COMP/2FAN/2SPR/PEDR	ALMR	ALMR	ALMR	ALMR
CYCF	FAN Cycle Mode ON/CYCL	CYCL	CYCL	CYCL	CYCL
DINM	Defrost Initiate Mode DEMD/SCHD	DEMD	SCHD	DEMD	SCHD
DFPD	# Of DEFROST per day	0	2	0	2
DFMD	Defrost Mode ELEC/RCD	RCD	ELEC	RCD	ELEC
INTV	Maximum Time Between Defrost	720 min	720 min	720 min	720 min
PMDN	Pump Down Time Before Defrost	1	1	1	1
CYCD	Defrost Heater Cycle Mode ON/CYCL	ON	CYCL	ON	CYCL
DTSP	Defrost Termination Setpoint	50F	45F	50F	45F
MXDT	Maximum Defrost Time	35 min	35 min	35 min	35 min
MNVP	Minimum Valve Position in Defrost	20%	0	20%	0
DRAN	Drain Time	5 min	5 min	5 min	5 min
DFFN	Defrost Fan State	OFF	OFF	OFF	OFF
FDTP	Fan Delay Temperature	20	55	20	55
MFDT	Maximum Fan Delay Time	5	5	5	5
FOFF	Fan off Temperature Setpoint	35	60	35	60
CLTD	Coil TD for demand defrost	10	10	10	10
MEVM	Multiple Evap Mode SYNC/ALTN	SYNC	SYNC	SYNC	SYNC
ALSP	Air DIFF. To Leave Alternating Mode	5	5	5	5
TBLL	Time between Lead/Lag				
HITA	HIGH Air Temperature ALARM Offset	20	20	20	20
LOTA	LOW Air Temperature ALARM Offset	10	10	10	10
HITD	High Air Temp DELAY	45 min	45 min	45 min	45 min
DI1M	DIGITAL INPUT 1 MODE DISA/SOFF/DOOR/2NRT/DFLO/DFIL	SOFF	SOFF	SOFF	SOFF
DI1S	DIGITAL INPUT 1 STATE OPEN/ CLOSE	CLOS	CLOS	CLOS	CLOS
DI2M	DIGITAL INPUT 2 MODE DISA/SOFF/DOOR/2NRT/DFLO/DFIL	DOOR	DOOR	DOOR	DOOR
DI2S	DIGITAL INPUT 2 STATE OPEN/CLOSE	CLOS	CLOS	CLOS	CLOS
DI3M	DIGITAL INPUT 3 MODE DISA/SOFF/DOOR/2NRT/DFLO/DFIL	DISA	DISA	DISA	DISA
DI3S	DIGITAL INPUT 3 STATE OPEN/CLOSE	CLOS	CLOS	CLOS	CLOS
RMT2	Room TEMP Sensor #2	-5	42	-5	42
HOUR	Hour of Day	N/A	N/A	N/A	N/A
MIN	Minute of Day	N/A	N/A	N/A	N/A
REFT	R-404a,R-22	404A	404A	404A	404A
VTYP	Valve Type MECH/KE2 RSV/SER 6/CUSTOM	SER 6	SER 6	SER 6	SER 6
SHSP	Superheat Set Point	10	10	10	10
MOP	Max Suction Pressure Setpoint	55	80	55	80
MTYP	EEV Motor Type (only for VTYP = CUSTOM)	-	-	-	-
RATE	Motor Step Rate (only for VTYP = CUSTOM)	-	-	-	-
MXST	Maximum Valve Steps (only for VTYP = CUSTOM)	-	-	-	-

ALARM DISPLAY

Any alarm will cause alarm relay to switch. All alarms have a distinct display shown on the four-digit display on the controller. The red LED will be on for a pressure or suction temperature sensor alarm and the amber LED will on for all other alarms. Multiple alarms can exist. There is a priority as to which alarm will be displayed before another.

ALARMS		PRIORITY
"ALST"	Description	
PRSA	PRESSURE SENSOR ALARM	1
STSA	SUCTION TEMP SENSOR ALARM	2
ATSA	AIT TEMP SENSOR ALARM	3
CTSA	COIL TEMP SENSOR ALARM	4
ATSA	AUX TEMP SENSOR ALARM	5
LOSH	LOW SUPERHEAT ALARM	6
HITA	HIGH TEMPERATURE ALARM	7
LOTA	LOW TEMPERATURE ALARM	7
LPRA	LOW PRESSURE ALARM	7
XTA1	EXTERNAL ALARM/ DIGITAL INPUT 1	8
XTA2	EXTERNAL ALARM/ DIGITAL INPUT 2	8
XTA3	EXTERNAL ALARM/ DIGITAL INPUT 3	8
DROA	DOOR OPEN ALARM	9
COMA	COMMUNICATION ALARM	10

Setting Parameters By On-Board Pushbuttons

There are two levels for programming the controllers with the four-digit display and six pushbuttons. The first level (User's Level) will enable the USER to set the room temperature set point 'RMSP'; the second level (Technician's Level) allows access to the other parameters as described above.

User's Level

Press the right or left button until 'STPT' (Set point) is displayed. Press the 'ENTER' button. If 'PSWD' (Password) is displayed, press the 'ENTER' button again. The display should read '0000' with the 0 on the right blinking. Enter the password '0001' by using the up and down buttons to increment or decrement the blinking digit, and the right or left buttons to move the blinking digit to the next digit. When the display reads '1111', press and hold the 'ENTER' button (about 3 seconds) until 'RMSP' (room set point) is displayed. Press the 'ENTER' button to display the value for 'RMSP'. If you want to change the value, press and hold the 'ENTER' button until the right digit starts blinking (about 3 seconds). Use the up and down buttons to increment or decrement the value. Use the right and left buttons to change the digit that is blinking. When the value that is wanted is displayed, press and hold the 'ENTER' button until the digit stops blinking (about 3 seconds). At any time, pressing the 'BACK' button will escape to the step before.

TECHNICIAN's Level

Press the right or left button until 'STPT' (Set point) is displayed. Press the 'ENTER' button. If 'PSWD' (Password) is displayed, press the 'ENTER' button again. The display should read '0000' with the 0 on the right blinking. Enter the password '0002' by using the up and down buttons to increment or decrement the blinking digit, and the right or left buttons to move the blinking digit to the next digit. When the display reads '0002', press and hold the 'ENTER' button (about 3 seconds) until a set point is displayed. Use the up and down buttons to get to the set point that is wanted. Press the 'ENTER' button to display the value for that set point. If you want to change the value, press and hold the 'ENTER' button until the right digit starts blinking (about 3 seconds). Use the up and down buttons to increment or decrement the value. Use the right and left buttons to change the digit that is blinking. When the value that is wanted is displayed, press and hold the 'ENTER' button until the digit stops blinking (about 3 seconds). At any time, pressing the 'BACK' button will escape to the step before.

MANUAL VALVE

Press the right or left button until 'MNMD' (Manual Mode) is displayed. Press the 'ENTER' button. If 'PSWD' (Password) is displayed, press the 'ENTER' button again. The display should read '0000' with the 0 on the right blinking. Enter the password '0002' by using the up and down buttons to increment or decrement the blinking digit, and the right or left buttons to move the blinking digit to the next digit. When the display reads '0002', press and hold the 'ENTER' button (about 3 seconds) until a manual mode is displayed. Use the up and down buttons to get to 'MVLV' (manual valve). Press the 'ENTER' button to display the value for the valve position. Use the up and down buttons to increment or decrement the percentage for the valve to be open. Use the right and left buttons to change the digit that is blinking. At any time, pressing the 'BACK' button will escape manual valve mode and go back to auto mode. If no buttons are pressed for 1 hour, the controller will go back to auto mode.

CLEAR ALARM

Press the right or left button until 'MNMD' (Manual Mode) is displayed. Press the 'ENTER' button. If 'PSWD' (Password) is displayed, press the 'ENTER' button again. The display should read '0000' with the 0 on the right blinking. Enter the password '0002' by using the up and down buttons to increment or decrement the blinking digit, and the right or left buttons to move the blinking digit to the next digit. When the display reads '0002', press and hold the 'ENTER' button (about 3 seconds) until a manual mode is displayed. Use the up and down buttons to get to 'ALST' (alarm status). Press the 'ENTER' button and the display will show 'CLAL' (clear alarm). Press and hold the 'ENTER' button until the display changes. The alarms have cleared. At any time, pressing the 'BACK' button will escape this mode the previous step.

MANUAL DEFROST

Press the right or left button until 'MNMD' (Manual Mode) is displayed. Press the 'ENTER' button. If 'PSWD' (Password) is displayed, press the 'ENTER' button again. The display should read '0000' with the 0 on the right blinking. Enter the password '0002' by using the up and down buttons to increment or decrement the blinking digit, and the right or left buttons to move the blinking digit to the next digit. When the display reads '0002', press and hold the 'ENTER' button (about 3 seconds) until a manual mode is displayed. Use the up and down buttons to get to 'MCTL' (manual control). Press the 'ENTER' button to display the mode that the controller is in. To change the mode, press and hold the 'ENTER' button (about 3 seconds) until the display changes to the next mode. If the controller was in 'COOL' or 'OFF', it will go to 'DEFR'. If the controller was in 'DEFR', it will go to 'DRAN'. If the controller was in 'DRAN', it will go to 'FNDL'. If the controller was in 'FNDL', it will go to 'COOL'. At any time, pressing the 'BACK' button will escape manual valve mode and go back to auto mode.

BOND CNTRLRS

Connect the controllers that need to communicate with each other using the RJ-45 connector of the controller to an ethernet switch or router. If there are just 2 controllers, you can connect them directly, without the ethernet switch or router. **Disconnect any other controller that is not going to communicate with this group of controllers.** On any of the controllers, press the right or left button until 'MNMD' (Manual Mode) is displayed. Press the 'ENTER' button. If 'PSWD' (Password) is displayed, press the 'ENTER' button again. The display should read '0000' with the 0 on the right blinking. Enter the password '0002' by using the up and down buttons to increment or decrement the blinking digit, and the right or left buttons to move the blinking digit to the next digit. When the display reads '0002', press and hold the 'ENTER' button (about 3 seconds) until a manual mode is displayed. Use the up and down buttons to get to 'BOND' (bond controllers). Press the 'ENTER' button and the display will show 'INBD' (initiate bonding). Press and hold the 'ENTER' button until the display changes. After 3 to 5 seconds, all connected controllers will reset. The bonding process is complete. At any time, pressing the 'BACK' button will escape this mode the previous step.

Temperature Sensors

The application range of the temperature sensors used for this controller is -60°F to +150°F. If the sensor detects a temperature out of the range, an alarm will show on the controller display.

Three temperature sensors are used in the Master Controller 2.0 refrigeration system. They are the room temperature return air sensor, the evaporator defrost termination temperature surface sensor and the evaporator outlet (suction line) temperature surface sensor. All sensors are solid state devices with the same characteristics that change electrical resistance in response to a change in temperature.

The room temperature sensor is factory-mounted on the lower back of the evaporator at the drain pan. This placement avoids heat from defrost heaters lights and still allows a good air stream over the sensor. Figure 3 shows a typical mounting of the room temperature sensor.

The defrost termination sensor is mounted on one of the distributor tubes close the end plate. The outlet sensor is mounted on the suction line at the outlet of the evaporator as shown in Figure 4. These sensors are interchangeable.



and
The coil

Figure 3

SENSOR SERVICE INSTRUCTIONS

Care must be taken when brazing the suction line at the evaporator. The outlet sensor must be taken out before brazing. After brazing, fasten the sensor with the metal strap provided. Make sure the sensor is tight and has good contact with the suction line.

The temperature sensor cannot be repaired. Using the measurements in Chart A below, you can determine if they are functioning correctly. If the sensors are found out of tolerance, they should be replaced.

As mentioned above, the temperature sensor changes electrical resistance in response to temperature changes. Disconnect the sensor from the controller, check the temperature at the sensor location, then check and record the resistance through the temperature sensor.




Figure 4

Procedures to check temperature sensor tolerance with ice water:

1. Use a cup of water with well-stirred ice. The water temperature should be an even 32°F.
2. Submerge the room temperature sensor (TS2) into the water while the Master Controller 2.0 is normally operating. Check the display for the value. If the sensor shows 32°F, it is working properly.
3. Press the right or left buttons until the display shows the name of one of the variables. Press the up or down buttons until the display reads 'TCOI', the defrost termination sensor (TS3). Press the 'ENTER' button to display the value. Submerge the sensor into the water. Check the display for the value. If the sensor shows 32°F, it is working properly.
4. Scroll down the display to "TSUC", the outlet sensor (TS1) value.
5. Submerge the outlet sensor into the water. Check the display for the value. Again, if the sensor shows 32°F, it is working properly.

Compare the temperature and resistance to Chart A.

Chart A. Temperature/Resistance Characteristics (-50 to 80 °F)

Temp. °F	Temp. °C	ohms*1k		Temp. °F	Temp. °C	ohms*1k
-50	-45.6	43.45		15	-9.4	7.579
-40	-40.0	32.31		20	-6.7	6.731
-35	-37.2	27.96		25	-3.9	5.993
-30	-34.4	24.27		30	-1.1	5.349
-25	-31.7	21.13		32	0	5.123
-20	-28.9	18.43		35	1.7	4.781
-15	-26.1	16.12		40	4.4	4.281
-10	-23.3	14.13		50	10.0	3.454
-5	-20.6	12.42		60	15.6	2.805
0	-17.8	10.94		70	21.1	2.294
5	-15.0	9.651		80	26.7	1.888
10	-12.2	8.544				

NOTE: Use resistance at 32°F for sensor checking.

Pressure Transducer

Your Master Controller 2.0 will be equipped with one of two types of pressure transducer (PT). The difference is in the color of sensor wires as noted below:

New PT (19-14226, 19-14223)	OLD PT (19-13955, 19-14092)	Description
RED	BLACK	+VDC (+5)
GREEN	WHITE	SIGNAL (sig)
BLACK	GREEN	GROUND (5-)

The **GROUND** is connected to terminal '5-' on the board. The **SIGNAL** lead is connected to terminal 'sig' on the board. The **+VDC** lead is connected to terminal '5+' on the board. Chart B shows the characteristics of the pressure transducer. **NOTE: The pressure transducer cannot be repaired but replaced only.**

Chart B. Pressure Sensor Simulation Values (0 to 150 PSIA)

Bar	PSIA	PSIG	V (Signal to Ground)
0	0	-14.6	0.509
0.69	10	-4.6	0.784
1.379	20	5.4	1.058
2.069	30	15.4	1.332
2.758	40	25.4	1.587
3.448	50	35.4	1.862
4.137	60	45.4	2.136
4.827	70	55.4	2.391
5.516	80	65.4	2.665
6.206	90	75.4	2.920
6.895	100	85.4	3.194
7.585	110	95.4	3.469
8.274	120	105.4	3.724

Charging the Master Controller 2.0 Refrigeration System

Note: If you are a first time installer of a Master Controller 2.0 system, please call Master-Bilt for on-phone training.

Since the system is designed with free floating head control, the head pressure control valve is not installed in this type of system. Therefore, the compressor operates at its highest EER value.

During initial pull down, after primary charge while the system is running, a large evaporator superheat is built up. The electric expansion valve is then open all the way. If the system is charged full sight glass during this period, the system is already overcharged.

Note: The liquid line size is determined by conventional piping practices for air and electric defrost. For reverse cycle defrost, the liquid line must be selected by choosing the liquid line one nominal step larger than the conventional approach. For example: for an evaporating temperature = -20°F, refrigerant R-404A, and a capacity of 20,000 Btuh, the conventional tables will suggest a liquid line size of 1/2" OD. When utilizing the reverse cycle feature of the Master Controller, the liquid line size should be 5/8" OD. When utilizing the electric or air defrost scheme, there is no need to make the line larger.

All suction lines may be chosen by conventional practices. Please note the "stubs" at both the evaporator and condensing unit do not necessarily mean that this is the correct size for your application.

Calculation of estimated amount of working refrigerant:

The amount of working refrigerant can be estimated by the following formula:

Tons of cooling capacity x 4.5 LBS/Ton + Full Liquid Line Charge between Evaporator and Condensing Unit

For example, a system of 12,000 BTUH @ -20F suction, 50 ft 1/2" liquid line run, R404A, 100F Liquid, the working amount of refrigerant is: $1 \times 4.5 + 6.5 \times 50/100 = 7.75$ LBS R404A. **The actual charge should be approximately this working amount of refrigerant.**

Weight of Refrigerant in LBS per 100 ft of Liquid Line:

Liquid Line Size, Inch	Refrigerant	Lbs of Refrigerant
3/8	R22	4.0
	R404A	3.5
1/2	R22	7.5
	R404A	6.5
5/8	R22	12.0
	R404A	10.5
7/8	R22	24.5
	R404A	21.0

The recommended charging procedures are:

- (1) Charge the system by weighing exact amount of refrigerant specified by Master-Bilt for the unit. Or,
- (2) Charge 50% of the liquid receiver (if provided) rated holding capacity. Let the system run through the pull down period until room temperature is closely reached, then gradually add refrigerant until actual superheat "SUPH" on board is approaching superheat setpoint "SHSP". Bubbles may be seen in the sight glass.
- (3) In a reverse cycle defrost system, there may not be a liquid receiver. Charge the system the working amount of refrigerant calculated above. Let the system run through the pull down period until room temperature is closely reached. Then gradually add refrigerant until actual superheat "SUPH" on board is approaching superheat setpoint "SHSP". Bubbles may be seen in the sight glass.

How to diagnose an overcharged system:

An overcharged system will not operate properly.

- First, be sure that system is not leaking
- Compressor may be short cycling
- Frost building up on compressor suction section, suction filter or service valve
- Low superheat alarm appears on the controller display constantly
- Head pressure cut-out during defrost for a reverse cycle defrost system

Solution:

Taking some refrigerant out of the system until on-board actual superheat "SUPH" is observed approaching superheat setpoint "SHSP".

Technical Notes

- With the optional alarm relay the external temperature and alarm indicator should be connected to "C" (common) and "NC" (normal close) terminals. The alarm does not indicate what causes the alarm. To find out what has caused the alarm, check the onboard four-digit display for alarm codes and refer to the diagnosis chart for corrective action. Thermostat wiring can be used for connection.
- Defrost termination set point (DTSP) can be also set up to 80°F. When setting the defrost termination temperature, make sure that the frost is free after each defrost. Also make adjustments to the maximum defrost duration when necessary.
- The superheat of each application can be set by the customer. Superheat 10-15°F is recommended for winter operation, superheat 5-10°F for summer.
- Always clear the "LOSH", "HITA" and "LOTA" alarms after corrective action is taken. The sensor and communication alarms cannot be cleared unless they are corrected.
- Cat5/e communication cable should be rated 300 V 80°C or higher. If the wire is rated lower than 300 V, a separate conduit must be used for communication cables.
- Follow the instructions in the Master-Bilt *Condensing Unit and Refrigeration System Installation & Operation Manual* to perform the final check up before charging and starting up the system. Always refer to this service manual, make sure all steps are understood. Don't hesitate to call Master-Bilt Customer Service Department at 800-684-8988 for technical assistance.

REVERSE CYCLE DEFROST

General Information

Master-Bilt's patented (U.S. patent no. 7,073,344) reverse cycle defrost is a standard feature on Master Controller-equipped refrigeration systems. A reverse cycle valve is already **factory-installed** on the condensing unit. The valve's primary function is to reverse the direction of the refrigerant flow during defrost. When the Master Controller's demand defrost determines that a defrost is necessary, the reverse cycle valve is activated and the high temperature refrigerant flow is reversed.

Under the normal refrigeration cycle, the refrigerant flow is the same as traditional refrigeration modes. During the defrost mode, the refrigerant flow is reversed back through the evaporator coil heating it from the inside-out along its entire length and completely eliminating frost buildup (see figure 5 below).




Figure 5

Advantages

Reverse cycle technology offers several significant advantages:

- **An up to 80% reduction in defrost energy usage.** This savings, coupled with that from the demand defrost feature, dramatically reduces energy consumption.
- Eliminates many mechanical parts
- Reduces cost of evaporator, installation and wiring
- Reduces defrost time
- No significant increase in freezer room temperature
- No noticeable increase in product temperature

Factory-Installed Parts

A 4-way reversing valve, operating at 24 VAC, is installed in a reverse cycle defrost unit. A transformer is also installed in the master evaporator to supply 24VAC to the 4-way reversing valve.

Eliminated Parts

The Master-Bilt Reverse cycle's unique technology, coupled with the bi-flow electric expansion valve, eliminates the need for:

- Defrost heaters
- Head pressure control valves
- Check valves and expansion valves at the condenser that are normally necessary in traditional hot gas defrost systems
- By-pass valves
- Liquid line solenoid valves
- Receiver tanks (except in B-series condensing units 6 HP and up)
- Sight glasses

Removing these components reduces the cost of the evaporator itself and saves on installation and wiring.

Defrost Time

Defrost time is greatly lessened with the reverse cycle option. The average time using electric defrost heaters is 20-30 minutes but reverse cycle performs a completely "clean" defrost typically in 3 – 5 minutes for freezers and 1½ – 2 minutes for coolers. Because the defrost is so rapid, there is no noticeable increase in freezer room temperature and the product temperature rise is also significantly less. Reverse cycle defrost, combined with demand defrost, assures the evaporator receives the number of complete defrosts needed at the necessary times to prevent iced evaporators while assuring the protection of the valued product being stored.

Charging a Master Controller 2.0 System Equipped with Reverse Cycle Defrost

Note: If you are a first time installer of a Master Controller 2.0 system, please call Master-Bilt for on-phone training.

Please refer to Page 21: Charging the Master Controller 2.0 Refrigeration System

Due to the reversing of the refrigerant flow, it is recommended that the refrigeration liquid line piping also be insulated to prevent condensation drips between the condensing unit and the evaporator coil.

ELECTRIC WIRING



WARNING

Please make sure to turn all power off before servicing electrical equipment. Always use a qualified and trained technician. If you are the technician and a first-time installer of a Master Controller 2.0 system, call our service department at 800-684-8988 for free training and support.


The field wiring for a Master Controller 2.0 refrigeration system includes the power supply to the condensing unit, the evaporator (fans, heaters and controller) and the communication cables between master and slaves. Thermostat wiring may be used for four-way reversing valve power supply since it is 24 VAC.

TYPICAL WIRING DIAGRAM (AIR DEFROST)

ADVANCED MASTER CONTROLLER WIRING 208-230/1-3/60 AIR DEFROST

MB MASTER-BILT®
Refrigeration Solutions

PLEASE CALL FACTORY SERVICE DEPT.
IF YOU ARE FIRST TIME INSTALLER
1-800-684-8988




TYPICAL WIRING DIAGRAM (REVERSE CYCLE DEFROST)

ADVANCED MASTER CONTROLLER WIRING 208-230/1-3/60 REVERSE CYCLE DEFROST

MBMASTER-BILT®
Refrigeration Solutions

PLEASE CALL FACTORY SERVICE DEPT.
IF YOU ARE FIRST TIME INSTALLER
1-800-684-8988




TYPICAL WIRING DIAGRAM (ELECTRIC DEFROST)

ADVANCED MASTER CONTROLLER WIRING 208-230/1-3/60 ELECTRIC DEFROST

MBMASTER-BILT®
Refrigeration Solutions

PLEASE CALL FACTORY SERVICE DEPT.
IF YOU ARE FIRST TIME INSTALLER
1-800-684-8988



Note: For feature configuration, please refer to the wiring diagram in the actual system for installation.

TROUBLESHOOTING GUIDE.

Trouble, Alarm Codes	Causes	Corrective Actions
Pressure transducer alarm PRSA	• Bad transducer • Out of range • Loose wire • Wrong hook-up	• Replace the pressure transducer • Turn off power for a few seconds, turn back on • Tighten the connections • Wire correctly
Outlet sensor TS2 fails STSA	• Mechanical damage • Connection wire loose • Overheated • Out of range	• Replace the sensor • Tighten the connection wires • When brazing suction line, take out the sensor • Install the sensor after brazing
Room sensor TS3 fails ATSA	• Mechanical damage • Connection wire loose • Overheated • Out of range	• Tighten the connection wires on the controller terminal • The room sensor can be replaced by surface sensor
Coil/defrost sensor TS1 fails CTSA	• Mechanical damage • Loose connection wire • Overheated • Out of range	• Tighten the connection wires on the controller terminal • Let the sensor cool down to application temperature range: -50°F to +103°F • Replace failed sensor
Aux sensor fails (if provided) T4SA	• Mechanical damage • Loose connection wire • Overheated • Out of range	• Tighten the connection wires on the controller terminal • Let the sensor cool down to application temperature range: -50°F to +103°F • Replace failed sensor
Low superheat LOSH	• Superheat setting too low • Wrong locations of TS2 • Sensors may be loose • Uneven feeding of coil circuits • Overcharge of refrigerant • Defective electric expansion valve (EEV) • Compressor stops	• Change to correct set point • Make sure the distributor is feeding each circuit evenly • Insulate the sensors with foam tape • Use correct refrigerant charge • Check EEV wiring • Replace defective EEV • Check compressor
High room temperature HITA	• Insufficient refrigeration • Heat load too large • Compressor fails or high pressure cuts out • Evaporator fans may not run • Door open for too long • Coil iced-up	• Check system design to select a sufficient system • Replace failed compressor • Fix the evaporator fans • Keep the cold room door closed during refrigeration • Check possible air leak through the walls of cold room
Low room temperature LOTA	• Improper low temp setpoint • Over designed system	• Change low temp set point • Re-select the system
Low pressure alarm LPRA	• Refrigerant leak • Bad transducer	• Fix leak • Replace pressure transducer
Digital Input 1 XTA1	• Incorrect digital input MODE • Mechanical damage • Loose connection wire • Out of range	• Correct the digital input MODE parameter • Tighten the connection wires on the controller terminal • Replace failed sensor/switch/relay
Digital Input 2 XTA2	• Incorrect digital input MODE • Mechanical damage • Loose connection wire • Out of range	• Correct the digital input MODE parameter • Tighten the connection wires on the controller terminal • Replace failed sensor/switch/relay
Digital Input 3 XTA3	• Incorrect digital input MODE • Mechanical damage • Loose connection wire • Out of range	• Correct the digital input MODE parameter • Tighten the connection wires on the controller terminal • Replace failed sensor/switch/relay
Door Alarm DROA	• Door are open • Incorrect parameter • Bad door switch	• Close door tightly • Declare the correct parameter relay (open/close) • Change the door switch
Communication COMA	• Loose RJ-45 connection • Failed communication port	• Replace connector • Change a new controller board

Troubleshooting the Electric Expansion Valve

If the valve stops moving, depending upon how far open it is, one or more alarms may be displayed. These alarms include a low superheat alarm, a low temperature alarm, and/or a high temperature alarm.

Use the following steps to troubleshoot the valve:

- 1) Disconnect the valve from the controller.
- 2) The resistance between the black and white leads should be 90 ohms. The resistance between the black and red leads should be an open.
- 3) The resistance between the red and green leads should be 90 ohms. The resistance between the white and green leads should be an open.
- 4) The resistance between each lead and the brass housing of the valve should be an open.
- 5) Read the AC, not DC, voltage across the black and white leads while the valve is moving. The AC voltage should be 11 to 13 VAC. The voltage will be close to 0 VAC when the valve is not moving.
- 6) Repeat step 5 across the red and green leads.

If any voltage is out of tolerance, replace the controller. If the above steps pass, inspect for contamination in the valve or nicks on the seat of the valve.

CAUTION: If the valve was taken apart and was left running while taken apart, the piston may have come too far out of the motor assembly. If you reassemble the valve with the piston in this position, the threads in the piston will be stripped when the piston is forced into the seat while tightening the lock nut. Make sure the piston is drawn up far enough into the motor assembly before reassembling.

MASTER-BILT PART NUMBERS

Use the chart below when ordering replacement parts for your Master-Bilt Master Controller 2.0 refrigeration system.

Item Description	Part Number	Notes
Master Controller 2.0 Board Med. Temp. Cooler	19-14285	Please re-set for applications
Master Controller 2.0 Board Low Temp. Freezer	19-14282	Please re-set for applications
Electric Expansion Valve	19-13772	Connections: SER-6-1/2"x1/2"
Electric Expansion Valve	19-13773	Connections: SER-6-5/8"x5/8"
Low Pressure Transducer	19-14223	Suction Pressure
4-Way Reversing Valve	09-09776	7/8" Connections, 24VAC Coil
4-Way Reversing Valve	09-09783	1 3/8" Connections, 24VAC Coil
Temperature Sensor	19-13967	30" Leads
Temperature Sensor	19-13968	10 ft Leads
24VAC Control RELAY	19-13986	For compressor control
24VAC, 40VA Transformer	39-01088	120/208/240 V Primary
Wireless Router	19-14294	
Fast MB Master-Controller, Commercial Range, 5 Port 10/100	19-14287	
Fast Ethernet Switch, 8 Port 10/100	19-14288	
Cable: 50 feet Ethernet Cat5e,	19-14290	With Ethernet Switch
Cable: 25 feet Ethernet Cat5e	19-14289	Use between AMCs
Cable: 100 feet Ethernet Cat5e	19-14291	With Ethernet Switch
Valve Test Kit	19-13786	Recommended for service
Fuse, BK/MDL-1/4, Time Delay, for AMC	19-14299	for AMC, Vendor: KE2Therm

For condensing unit installation and wiring, please consult the *Master-Bilt Condensing Unit System Installation and Operation Manual*. If any discrepancy is found in this manual, please contact Master-Bilt Technical Service Department immediately.



908 Highway 15 North
New Albany, MS 38652
Service Dept. phone: 800-684-8988
Fax: 866-882-7629
Email: service@master-bilt.com

Rev. 4-7-2015

©2015 Master-Bilt Products, an unincorporated division of Standex International Corporation. All rights reserved. Printed in U.S.A.

- Indicator lights**
-  **Red light** - critical alarm (system off)
 -  **Yellow light** - non-critical alarm (system running)
 -  **Green light** - compressor on
 -  **Green flashing** - compressor waiting on timer to start/stop

Move through controller menus:



Left Arrow and Right Arrow
Use to move between **Menus**

Up Arrow and Down Arrow
Scroll through **Menu Parameters**

Return to Main Menu:  Press BACK to return to the previous view.

Change settings:  Press & hold ENTER for 3 seconds, when display begins blinking changes can be made

Save setting changes:  Press and hold ENTER for 3 seconds to save change

Variables

RMTP – Room Temp
 SUPH – Superheat
 PRES – Suction Pressure
 TSUC – Suction Temperature
 TSAT – Saturated Temperature
 TCOI – Coil Temperature
 VALV – Valve Position
 TAUX – Auxiliary Temperature
 STAT – Status Refr/Off/Defrost/Drain/Fan delay
 RLCM – Compressor Relay On/Off
 RLDF – Defrost Relay On/Off
 RLFN – Fan Relay On/Off
 RLAU – Aux Relay On/Off
 D1ST- Digital Input 1 Status
 D2ST – Digital Input 2 Status
 D3ST – Digital Input 3 Status
 IPQ1 – First Quadrant of IP address
 IPQ2 – Second Quadrant of IP address
 IPQ3 – Third Quadrant of IP address
 IPQ4 – Fourth Quadrant of IP address
 NET1 – First Quadrant of Subnet Mask
 NET2 – Second Quadrant of Subnet Mask
 NET3 – Third Quadrant of Subnet Mask
 NET4 – Fourth Quadrant of Subnet Mask
 FWRV – Firmware Version 2.0v23

Manual

MCTL – Manual Status
 MVLV – Manual Valve
 CLAL – Clear Alarm
 BOND – Bond Controllers

REL4 – Aux Relay Functionality

SetPoints

RMSP – Room Air Set Point
 ADIF – Room Air Differential
 MRTM – Minimum Run Time
 MOTM – Minimum Off Time
 MNPR – Minimum Pressure Set Point
 T4TP – Aux Temp Functionality DISA/T4RT/T4CL
 CYCF – Fan Cycle Mode
 DIMN – Digital Initiate Mode DEMD/SCHD
 DFPD – # of Defrosts Per Day
 DFMD – Defrost Mode ELEC/RCD
 INTV – Maximum time Between Defrosts
 PMDN – Pump Down Time Before Defrost
 CYCD – Defrost Heater Cycle Mode
 DTSP – Defrost Term. Temp Set Point
 MXDT – Maximum Defrost Time
 VMOP – Valve Minimum Open during Defrost
 DRAN – Drain time
 DFFN – Defrost Fan State
 FDTP – Fan Delay Temperature
 MFDT – Maximum Fan Delay Time
 FOFF – Fan off Temperature setpoint
 CLTD – Coil TD for Demand Defrost
 MEVM – Multi Evap Mode SYNC/ALTN
 ALSP – Air Diff. to Leave Alternating Mode
 TBLL – Time between Lead/Lag
 HITA – High Air Temperature Offset
 LOTA – Low Air Temperature Offset
 HITD – High Air Temperature Delay
 DI1M – Digital Input 1 Mode DISA/ATP2/DOOR/EXT1/SOFF/DINT/DLCK
 DI1S – Digital Input 1 State OPEN/CLOS
 DI2M – Digital Input 2 Mode DISA/ATP2/DOOR/EXT2/SOFF/DINT/DLCK
 DI2S – Digital Input 2 State OPEN/CLOS
 DI3M – Digital Input 3 Mode DISA/ATP2/DOOR/EXT3/SOFF/DINT/DLCK
 DI3S – Digital Input 3 State OPEN/CLOS
 RMT2 – Second Room Air Set Point
 HOUR – Hour of the Day
 MIN – Minute of the Day
 REFT – Refr type 404a, R22
 VTYP – Valve type MECH/SERB/CUST
 SHSP – Superheat Set Point
 MOP – Maximum Pressure Set Point
 MTYP – EEV Motor Type (for VTYP = CUST only)
 RATE – Motor Steps Rate (for VTYP = CUST only)
 MXST – Max Valve Steps (for VTYP = CUST only)

Alarms

PRSA – Pres Sensor Alarm
 STSA – Suction Temp Sensor Alarm
 ATSA – Air Temp Sensor Alarm
 CTSA – Coil Temp Sensor Alarm
 T4SA – Aux Temp Sensor Alarm
 LOSH – Low Superheat Alarm
 HITA – High Air Temp Alarm
 LOTA – Low Air Temp Alarm
 LPRA – Low Pressure Alarm
 DROA – Door Open Alarm
 COMA – Communication Alarm
 XTA1 – External Alarm/Digital Input 1
 XTA2 – External Alarm/Digital Input 2
 XTA3 – External Alarm/Digital Input 3